

To use them, you have to physically patch the outputs of the MIC INPUTS into your choice of ANALOG INPUTS 1-4 (Input 1 is pre-configured for this). Likewise, to use the PR&E Mix Engine with the 5-port switch, you need to physically jumper the ETHERNET OUT to an available port on the onboard 5-port **ETHERNET** switch.

Designed and built in the USA.

Phone +1-252-638-7000 pre.com | sales@wheatstone.com